

Electrical heating cable for freeze protection of rails, switch points, tramways and monorails.

- Outputs available up to 220W/m.
- Heated lengths up to 6 metres for turnouts. Available for 115 & 230VAC (nom).
- Can be cut-to-length to suit switch size.

Rail & Switch Point Heater

- Full range of controls and accessories.
- Voltages to 1000V AC or DC for 3rd rails.

DESCRIPTION

Rail heater type RHT is a parallel resistance, constant power output cable for use on main rail switch point systems, electrified 3 rails, monorails and tramway systems.

RHT is a cut-to-length cable designed to maintain snow and ice free systems to ensure track operational integrity in winter conditions. Simple and quick installation ensures minimum track possession time.

When used for point heating systems RHT is intended to be pre-terminated in 3m; 4m; 5m & 6m heated lengths to suit the turnout dimensions. It is suitable for direct replacement of existing strip heaters on the stock rails and switch rails.

The cable is designed to utilise rail industry standard and approved heater retaining clips. Thermally insulated capping is also available if required.

ACCESSORIES

Heat Trace supply a complete range of rail heater accessories: termination components, c/w remote end seal and sealant; EPR cold lead to heater power connection kit; EPR 2 core cold lead cable; thermally insulated capping; heater retaining clips; termination, installation and testing instructions. These items are recommended for the correct usage and operation of RHT heaters.

FURTHER INFORMATION:

Please consult the appropriate TK/RHT termination instructions and the RHT Installation Instructions (currently under revision) contact HTL for details.







SPECIFICATION

MAXI	NUM EXPOSURE	continuo	us 350°C (64	4°F)	
TEMP	ERATURE:	intermitta	nt 425°C (79	97°F)	
MININ	IUM INSTALLAT	ION			
TEMP	ERATURE:		-65°C (-85°F)	
POWER SUPPLY:		230 o	or 115VAC (no	ominal)	
(voltages also available to order 24V to 1000V AC or DC)					
WEIGI	HTS & DIMENSI	ONS:			
Type Ref	Dimensions (mm)+/-0.5	Weight kg/100m	Min Bending radius	Gland Size	
RHT	10 x 7	16.5	25mm	M20	

ORDERING INFORMATION:

	Example:	220 RHT 2 - F
Output 220W/m Rail heater RHT Supply Voltage 230V AC Fluoropolymer overjacket - (optional)*	Supply Voltage 230V AC	

IMPORTANT NOTES 1:

The RHT range of rail heaters should only be fitted to rails using the manufacturer's recommended and approved methods. The heating cables should only be terminated in accordance with the manufacturer's instructions, in order to ensure the heaters integrity is not compromised.

When the heater is being used on 3rd/live rails, outer insulating jackets of fluoropolymer are available and are extruded over the outer metal jacket. *This jacket will reduce the maximum withstand of the cable to $265^{\circ}C$ ($509^{\circ}F$).

Full details of all control and ancillary equipment is available on request.

MAXIMUM CIRCUIT LENGTH:

OUTPUT	MAX.CIRCU	IT LENGTH*	ZONE LENG	TH (NOM)
(W/m)	115V	230V	115V	230V
100	16m	32m	Zone len	gths can
150	13m	26m	vary. Co	ntact HTL
220	11m	22m	for info	rmation.

* For 10% end-to-end power output variation

POWER CONVERSION FACTORS:				
115V HEATING CABLE	230 HEATING CABLE			
277V Multiply output by 5.80	277V Multiply output by 1.45			

230V Multiply output by 4.00
240V Multiply output by 1.09
208V Multiply output by 3.27
220V Multiply output by 0.91
208V Multiply output by 1.09
208V Multiply output by 0.82
110V Multiply output by 0.91
115V Multiply output by 0.25

IMPORTANT NOTES 2:

When fitting the RHT range of rail heaters it is important to ensure that the rail profile reference is known. This is so that the right clips can be provided, to ensure correct fitment to the rail. The heaters need to be kept in contact with the rail, but still retain the ability to move logitudinally under normal expansion and contraction and to withstand the vibration and flexing of the rail during the expected operating conditions. It is recommended that clips are provided on either side of each bearer - as shown in the image below.



Recommended Heater & clip position (UIC60/60B rail)





Heat Trace Ltd, Mere's Edge, Chester Road, Helsby, Frodsham, Cheshire, WA6 0DJ, England. Tel: +44 (0)1928 726451 Fax: +44 (0)1928 727846 www.heat-trace.com email: info@heat-trace.com

The information given herein, including drawings, illustrations and schematics (which are intended for illustration purposes only), is believed to be reliable. However, Heat Trace Ltd makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. Users of Heat Trace Ltd products should make their own evaluation to determine the suitability of each such product for specific applications. In no way will Heat Trace Ltd be liable for any damages arising out of the misuse, resale or use of the product.